


*Camber arms seated too wide on mast*



*Camber arms seated correctly on mast*



The easiest way to re-adjust your camber back to a regular diameter setting is to use the batten tension key (found in a small pocket at the foot of your Ezzy Sail).



**Adjust webbing length**



**for skinny masts**



**Standard diameter masts**